

## GX-215 ストップリスト

### **PEDAL**

32 CONTRA VIOLONE  
16 PRINCIPAL  
16 BOURDON  
16 LIEBLICH BOURDON (SW)  
8 OCTAVE  
8 FLUTE  
4 SUPER OCTAVE  
MIXTURE IV  
16 BOMBARDE  
4 CLARION  
GENISYS VOICE 1 (OPTIONAL)  
GENISYS VOICE 2 (OPTIONAL)  
GREAT TO PEDAL  
SWELL TO PEDAL

### **SWELL**

8 ROHR BOURDON  
8 VIOLE  
8 VOIX CELESTE  
4 GEIGEN OCTAVE  
4 TRAVERSE FLUTE  
2-2/3 NASARD  
2 PICCOLO  
1-3/5 TIERCE  
PLEIN JEU IV  
16 BASSON  
8 TROMPETTE  
8 HAUTBOIS  
TREMULANT  
CELESTA  
SWELL UNISON OFF  
GENISYS VOICE 3 (OPTIONAL)  
GENISYS VOICE 4 (OPTIONAL)

### **GREAT**

16 VIOLONE  
8 PRINCIPAL  
8 HARMONIC FLUTE  
8 FLUTE DOLCE CELESTE II (SW)  
4 OCTAVE  
4 FLUTE  
2 FIFTEENTH  
MIXTURE IV  
8 TRUMPET  
8 KRUMMHORN  
TREMULANT  
CHIMES  
GENISYS VOICE 5 (OPTIONAL)  
GENISYS VOICE 6 (OPTIONAL)  
SWELL TO GREAT

### **GENERAL**

BASS COUPLER  
MELODY COUPLER  
ALTERNATE TUNING  
TREMULANTS FULL  
GENISYS VOICES COUPLE  
EXTERNAL SPEAKERS OFF  
CONSOLE SPEAKERS OFF

### **MIDI**

MIDI ON PEDAL  
MIDI ON SWELL  
MIDI ON GREAT