

GX-450 ストップリスト

PEDAL

32 CONTRA VIOLONE
16 DIAPASON
16 BOURDON
16 BOURDON DOUX (SW)
16 VIOLONE
16 CONTRA GAMBE (SO)
8 OCTAVE
8 GEDACKT FLÖTE
8 GAMBA (SO)
4 CHORALBASS
4 FLÛTE
MIXTURE IV
32 CONTRE BOMBARDE
16 BOMBARDE
16 CONTRE TROMPETTE (SW)
8 TROMPETTE
4 CLARION
GENISYS VOICE 1
GENISYS VOICE 2
BASS COUPLER

SWELL

16 BOURDON DOUX
8 GEIGEN DIAPASON
8 BOURDON
8 SALICIONAL
8 VOIX CELESTE
4 OCTAVE GEIGEN
4 TRAVERSE FLUTE
2-2/3 NASARD
2 PICCOLO
1-3/5 TIERCE
FOURNITURE IV
16 CONTRE TROMPETTE
8 TROMPETTE
8 HAUTBOIS
8 VOX HUMANA
4 CLAIRON

TREMULANT

16 SWELL
UNISON OFF
4 SWELL
GENISYS VOICE 3
GENISYS VOICE 4

GREAT

16 VIOLONE
8 DIAPASON
8 HARMONIC FLUTE
8 GAMBA
4 OCTAVE
4 SPITZ FLUTE
2-2/3 TWELFTH
2 FIFTEENTH
MIXTURE IV
8 KRUMMHORN
16 DOUBLE TRUMPET
8 TROMBA
CHIMES
TREMULANT
GENISYS VOICE 5
GENISYS VOICE 6

CHOIR

16 CONTRA VIOLE
8 DIAPASON
8 HOLZ GEDACKT
8 VIOLE
8 VIOLE CELESTE
4 PRINZIPAL
4 KOPPELFLÖTE
4 VIOLES II
2 OKTAV
1-1/3 QUINTFLÖTE
CYMBALE III
UNISON OFF
TREMULANT
GENISYS VOICE 7
GENISYS VOICE 8
MELODY COUPLER CH>GT

SOLO

16 GAMBA CELESTE II
8 SOLO GAMBA
8 GAMBA CELESTE
4 GAMBETTE CELESTE II
8 FLAUTO MIRABILIS
8 TUBA MIRABILIS
8 FRENCH HORN
8 CORNO DI BASSETTO
8 COR ANGLAIS
TREMULANT
GENISYS VOICE 9
GENISYS VOICE 10

GENERAL

MAIN ORGAN OFF
ANTIPHONAL ORGAN ON
GT-CH MANUAL TRANSFER
TREMULANTS FULL
ALTERNATE TUNING

COUPLERS

8 GREAT TO PEDAL
8 SWELL TO PEDAL
4 SWELL TO PEDAL
8 CHOIR TO PEDAL
8 SOLO TO PEDAL
16 SWELL TO GREAT
8 SWELL TO GREAT
4 SWELL TO GREAT
8 CHOIR TO GREAT
8 SOLO TO GREAT
16 SWELL TO CHOIR
8 SWELL TO CHOIR
4 SWELL TO CHOIR
8 SOLO TO CHOIR
8 SOLO TO SWELL
GENISYS VOICES
ALL SWELLS TO SWELL
GT-PD UNENCLOSED
CHOIR UNENCLOSED

MIDI

MIDI ON PEDAL
MIDI ON SWELL
MIDI ON GREAT
MIDI ON CHOIR
MIDI ON SOLO